
# **Torque Hinges**

**Fixed Torque, Adjustable Torque** 







#### Part Name Material 1)Hinge Plate EN 1.4301 Equiv. 2 Plastic Barrel Polyacetal EN 1.4305 Equiv. EN 1.4301 Equiv. (4)Plate ⑤Swage Pin EN 1.4567 Equiv.

- · Use two hinges for one door/lid
- · Align the axes of the two hinges.
- Do not use the hinges outdoors or in any places where oil or grease adheres to the hinges.
   Do not use the hinges in any places requiring continuous open-close movements.
- Given the product characteristics, vertical usage is not assumed. For vertical use, adjust allowable load and torque value to the actual operating conditions.

Operating Temp. Range: -10°C ~ 50°C Operating Humidity Range: 90%RH or lower


| Part Number |     | Rated Torque* |        | Mass |    | w  | Р  | J   | s  | _   | Е    | R   | Unit Price     | Volume Discount Rate |
|-------------|-----|---------------|--------|------|----|----|----|-----|----|-----|------|-----|----------------|----------------------|
| Туре        | No. | N⋅m           | kgf·cm | (g)  | -  | ** | -  | "   | 3  | •   | -    | "   | 1 ~ 19 pc (s). | 20~50                |
| ННРТ        | 3   | 0.35          | 3.4    | 15   | 32 | 36 | 18 | 7.5 | 21 | 1.2 | 4.25 | 7.5 |                |                      |
|             | 7   | 0.7           | 6.9    | 28   | 40 | 48 | 26 | 8   | 32 | 1.2 | 4.75 | 8.5 |                |                      |
|             | 15  | 1.5           | 14.7   | 64   | 50 | 48 | 36 | 8   | 32 | 2   | 6.5  | 12  |                |                      |











Onening / Closing Frequency-Values are measured by using HHPT15 for reference, and not quaranteed Opening/closing frequency: 5 times per minute (0° ~ 160° per opening/closing)
\* The torque is set to a value higher than the rated torque before shipping considering the torque degradation due to aging and temperature/humidity change


■How to Select Torque Hinges

When operated as a lid as shown on right, calculate the necessary torque according to the following formula before selecting a torque hinge that satisfies the specifications. (Assume that the lid's center of gravity lies in the middle.)

[Formula] Max. Torque T= L / 2 x m (Weight: kg) x 9.8 (Newton: N)

(Ex.) When L=0.3m and m=2kg, Max. Torque T =0.3/2x2x9.8=2.94N⋅m.





|    | Part Number    |     | * Allowable Load ** Rated Torqu |    | ** Dated Targue |        | Mass (g) |            | P <sub>1</sub> | P <sub>2</sub> | J    | Clear Anodize        |            | Black Anodize        |      |
|----|----------------|-----|---------------------------------|----|-----------------|--------|----------|------------|----------------|----------------|------|----------------------|------------|----------------------|------|
|    |                |     |                                 |    | a Torque        | S      |          | Unit Price |                |                |      | Volume Discount Rate | Unit Price | Volume Discount Rate |      |
|    | Туре           | No. | kg                              | N  | N·m             | kgf∙cm | (9)      |            |                |                |      | 1 ~ 8 pc (s).        | 9~50       | 1 ~ 8 pc (s).        | 9~50 |
| H  | HPTF           | 6   |                                 |    | 0               | 0      |          | 32         | 16             | 16             | 13.5 |                      |            |                      |      |
| H  | HPTFB          | 8-6 | 10                              | 98 | ì               | ì      | 54       | 37         | 16             | 21             | 13.5 |                      |            |                      |      |
| (E | Black Anodize) | 8   |                                 |    | 4.9             | 50     |          | 42         | 21             | 21             | 8.5  |                      |            |                      |      |

<sup>\*</sup> The allowable load is the value when 2 pieces are used.
\*\* Rated torque value is for a single hinge.





### Example

Use a hex wrench to adjust torque value. ¶ If tightened with a force of 1.5N ⋅ m or more, a hex wrench might be damaged.





Table of Weight Selection Guide (per Hinge)

|   | _        | -   | •                                |                |               |      |
|---|----------|-----|----------------------------------|----------------|---------------|------|
|   | (g       | kg  | 0.10 0.15 0.20 0.25 0.30 0.35    | 0.40 0.45      | 0.50 0.55     | 0.6  |
|   | Mass (kg | 8.0 |                                  |                |               |      |
|   | as       | 0.9 |                                  |                |               |      |
|   | Σ        | 1.0 |                                  |                |               |      |
| _ |          | 1.1 | Part Number                      |                |               |      |
|   |          | 1.3 | HHPTF6, HHPTF8-6,                |                |               |      |
|   |          | 1.4 | HHPTF8, HHPTFB6,                 |                |               |      |
|   |          | 1.5 | HHPTFB8-6, HHPTFB8               |                |               |      |
|   |          | 1.6 |                                  |                |               |      |
|   |          | 1.7 |                                  |                |               |      |
| _ |          | 1.8 |                                  |                |               |      |
|   |          | 2.0 |                                  |                |               |      |
|   |          | 2.1 |                                  | J              |               |      |
|   |          | 2.2 |                                  |                |               |      |
|   |          | 2.3 |                                  |                |               |      |
|   |          | 2.4 |                                  |                |               |      |
|   |          | 2.5 | [Formula]                        |                |               |      |
|   |          | 2.6 | Max. Torque T = L/3 *Torque is c | 2 x m (Weight: | kg) x (Newton | : N) |
|   |          | 2.7 | HHPTFB. A                        |                |               |      |
|   |          |     |                                  |                |               |      |

Guide - Door Dim." below.

Door Dim. (m) 0.10 0.15 0.20 0.25 0.30 0.35 0.40 0.45 0.50 0.55 0.60


## **Damper Hinges**




| Part Nu | mber | Reverse<br>Torque | Max.<br>Operating | Operating Temp. | Mass | Unit Price     | Volume Discount Rate |
|---------|------|-------------------|-------------------|-----------------|------|----------------|----------------------|
| Туре    | No.  | (N·m)*            | Angle             | Range (°C)      | (g)  | 1 ~ 19 pc (s). | 20~50                |
|         | 1A   | 0.49~1.27         | 110               | 0~40            | 46   |                |                      |
| HHPR    | 1B   |                   |                   |                 |      |                |                      |
| HHEN    | 2A   |                   |                   |                 |      |                |                      |
|         | 2B   |                   |                   |                 |      |                |                      |

\* Reverse torque value is for a single damper hinge.







| Parl                                | Number                   | Shaft Rotating       | Max. Reverse    | Unit<br>Price |  |  |  |  |
|-------------------------------------|--------------------------|----------------------|-----------------|---------------|--|--|--|--|
| Туре                                | Max. Usable Torque (N·m) | Direction            | Torque<br>(N·m) |               |  |  |  |  |
|                                     | 3                        |                      | 0.4 or Less     |               |  |  |  |  |
| MSDH                                | 5                        | L (Counterclockwise) | 0.6 or Less     |               |  |  |  |  |
| MODIL                               | 7.5                      | R (Clockwise)        | 0.8 or Less     |               |  |  |  |  |
|                                     | 10                       |                      | 1.0 or Less     |               |  |  |  |  |
| Torque value is for a single hinge. |                          |                      |                 |               |  |  |  |  |


should be considered as references only.

### <Basic Principle>

The rotation of the vanes compresses the oil and generates control (brake) force to act against work force.



### Reverse torque is torque in the opposite direction **■**Table of Selection Guide



### How to Select a Damper Hinge



The lid in a horizontal position generates maximum torque as shown on the left. Calculate maximum torque according to the following formula before selecting a damper that satisfies the specifications.

Max. Torque T= L/2 x m (Weight: kg) x 9.8 (Newton: N)

Ex.) When L=0.4m and m=5kg, Max. Torque T =0.4/2x5x9.8=9.8N · m

⇒ MSDH10 is selected.

Note) The selection made by the calculation above is for reference only.

The friction resistance and the effect of inertia moment at the hinge were not taken into consideration in the example above. The viscosity of the oil in the damper changes depending on the temperature of the operating environment. Generally, the damping